

# Lanyard ID Wallet Project

www.yoansewingstudio.com

www.youtube.com/yoansewingstudio



## Supplies

Main Fabric : 1 Fat Quarter or 1/6 yard of fabric\*

Lining Fabric : 1 Fat Eighth or 1/8 yard of fabric\*

Note : You may also mix and match any scraps or leftover fabric that you might have on hand.

\*based on regular 44" wide cotton quilting fabric

3 1/2" x 2 1/2" (9 x 6.4 cm) clear vinyl (I use gauge 8 vinyl) <https://amzn.to/36lXkoA>

9" x 6" (23 x 15.2 cm) Fusible Fleece (I use Pellon TP971F) <https://amzn.to/2Zj8wQu>

4 1/2" x 4" (11.4 x 10.2 cm) fusible woven interfacing - Pellon SF 101 <https://amzn.to/346atRJ>

(2) all purpose zipper 1" (2.5cm) wide at least 6" (15.2 cm) long <https://amzn.to/38xzWYa>

1" (2.5 cm) diameter key ring <https://amzn.to/2UhdXwe>

1/2" (12mm) swivel hook <https://amzn.to/3eKW2HD> <https://amzn.to/36lXkoA>

## Tools

Basic sewing notions

Walking foot/ teflon foot to sew the vinyl

Polyester thread

Note : This post may contain affiliate links; meaning I earn a small percentage of commission when you make a purchase of qualifying items through any of those with no additional charge. Thank you for your support!

## Finished wallet measurements :

Approx. 4 1/2" x 3 1/2" (11.4 x 9 cm)

Strap drop : 18" (45.7 cm)

## Abbreviation

FWI : Fusible woven interfacing

FF : Fusible Fleece



main fabric



lining fabric

watch the video tutorial :

[https://youtu.be/5M8dJC\\_u3oU](https://youtu.be/5M8dJC_u3oU)

## Cutting

### Front

ID pocket

cut 1x from the clear vinyl : 3 1/2" x 2 1/2" (9 x 6.4 cm)

cut 2x each from the main fabric and lining fabric : 3 1/2" x 1 1/2" (9 x 3.8 cm) for the side panels

cut 2x each from the main fabric 4" x 1 1/2" (10.2 x 3.8 cm) for the binding



clear vinyl



side panels



binding

Front Exterior

cut 1x from the main fabric : 5 1/2" x 4" (14 x 10.2 cm)

cut 1x from fusible fleece : 4 1/2" x 3" (11.4 x 7.6 cm)



Front Exterior



FF

### Back (Zipper Pocket)

Panel 1

cut 1x from the main fabric : 5 1/2" x 1 1/2" (14 x 3.8 cm)

cut 1x from the fusible woven interfacing 4 1/2" x 1 1/2" (11.4 x 3.8 cm)



Panel 1



FWI

Panel 2

cut 1x from the main fabric 5 1/2" x 2 1/2" (14 x 6.4 cm)

cut 1x from the fusible woven interfacing 4 1/2" x 2 1/2" (11.4 x 6.4 cm)



Panel 2



FWI

Panel 3

cut 1x from the lining fabric 5 1/2" x 2 1/2" (14 x 6.4 cm)



Panel 3

Panel 4

cut 1x from the lining fabric 5 1/2" x 4" (14 x 10.2 cm)

cut 1x from the fusible fleece 4 1/2" x 3" (11.4 x 7.6 cm)



Panel 4



FF

Zipper Tabs

cut 2x from the main fabric : 2" x 1" (5 x 2.5 cm)



Zipper tabs

### Ring Tab

cut 1x from the main fabric 2 1/2" x 2" (6.4 x 5 cm)



### Lanyard strap


cut 1x from the main fabric 36" x 2" (91 x 5 cm)



lanyard strap

### Interior

cut 2x from the lining fabric 5 1/2" x 4" (14 x 10.2 cm)



interior

## Brief Directions

(please refer to the video tutorial for more detailed demonstration)

1. Apply FWI to the following : Panel 1, Panel 2 (center the position)
2. Apply FF to the following : Front exterior, Panel 4 (center the position)
3. Sew and install the clear vinyl pocket to the front exterior.
4. Sew the back zipper pocket.
5. Sew and install the ring tab  
Note : make sure to install the ring tab on the same side as the id (vinyl) pocket opening.
6. Sew the lanyard strap (install the swivel hook simultaneously)
7. Install the zipper closure
8. Assemble the wallet (remember to leave an opening at the bottom part of the lining)
9. Turn the wallet right side out through the opening.
10. Sew the opening hole to close it, attach the lanyard strap to the key chain ring.

You are done!!

watch the video tutorial :

[https://youtu.be/5M8dJC\\_u3oU](https://youtu.be/5M8dJC_u3oU)